

AD-E100 315

66159

November 1979

Book 3

EVELO



SOFTWARE MAINTENANCE MANUAL FOR THE

MODULAR SYSTEM CONTROL **DEVELOPMENT MODEL (MSCDM)**

for

THE DEFENSE COMMUNICATIONS AGENCY WASHINGTON, D.C. 20305

11

Burroughs Corporation

Federal and Special Systems Group

Paoli, Pa. 19301



SECURITY CLASSIFICATION OF THIS PAGE (When Date	Entered)			
REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM		
1. REPORT NUMBER	2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER		
66159				
4. TITLE (and Subtitie)		5. TYPE OF REPORT & PERIOD COVERED		
Software Maintenance Manual for the Modular System Control Development Model (MSCDM) Book 3		FINAL Sep 76 - Nov 79		
		6. PERFORMING ORG. REPORT NUMBER		
7. AUTHOR(•)		B. CONTRACT OR GRANT NUMBER(*)		
		DCA100-76-C-0083		
9. PERFORMING ORGANIZATION NAME AND ADDRESS		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS		
Burroughs Corporation		PE 33186		
Federal and Special Systems Group Paoli, PA 19301		T&CCP 3012 Task 15203		
11. CONTROLLING OFFICE NAME AND ADDRESS		12. REPORT DATE		
Defense Communications Agency Defense Communications Engineering	Conton	November 1979		
1860 Wiehle Ave., Reston, VA 2209		87		
14. MONITORING AGENCY NAME & ADDRESS(If differen		15. SECURITY CLASS. (of this report)		
		UNCLASSIFIED		
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE		
16. DISTRIBUTION STATEMENT (of this Report)				
Approved for Public Release; Distr	ribution Unlimite	d		
Approved for Fubric Refease, 5.30.	Thucton on thin tee	ď		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, If different from Report)				
18. SUPPLEMENTARY NOTES				
19. KEY WORDS (Continue on reverse side if necessary an	nd identify by block number)			
Dungan Flow Chante	Madulan Anchita	.+		
Program Flow Charts Modular Architecture Loop Network DCS System Control				
Ring Network Distributed Computer System				
Ning house. K	0.00	pader system		
20. ABSTRACT (Continue on reverse side if necessary and	d identify by block number)			
Program flow charts for each Modul	ar System Contro	1 Development Model (MSCDM)		
program is presented. Flow charts for all operating system, application, diagnostic and utility programs are included in this single volume.				
7	9 22	5 042		
	•			



Foreword

This publication is the Software Maintenance Manual for the Modular System Control Development Model (MSCDM). This manual was prepared by the Burroughs Corporation and is submitted in accordance with the requirements of Contract DCA 100-76-C-0083.

Accessi		_/
NTIS (
DOC TAI	3	H
Unanno	inced	
Justif	ication_	
Ву		
Distri	bution/	
	ability	
Avail		
	Avail an	1/01
Dist	specia	LL
A		
111		

5.0 MSCDM SOFTWARE FLOW CHARTS

	Page
INTRODUCTION	1
SOFTWARE GENERATION CHART	3
DMCP FLOW CHART	4
sscu	11
vsqc	12
DSQC	15
DBMS	19
OCRI	20
BWBSA	21
FIAC	22
SDCA	27
SIG	30
SDCA5-11/40	33
USER LANGUAGE (USRLNG)	34
WRTDB	40
DIAGNOSTICS	70
IEEE PROGRAM	75
LOADER PROGRAM	76
LOADER PROM	83

INTRODUCTION

The Modular System Control Development Model (MSCDM) consists of nine functional nodes: Station-to-Station Communications Interface (SSCI), Voice Service Quality Control (VSQC), Digital Service Quality Control (DSQC), Data Base Management Service (DBMS), Operator Control and Report Interface (OCRI), Baseband Signal Analysis and Wide Band Signal Analysis (BWBSA), Fault Isolation and Control Coordination (FIAC), Switch Data Collection and Analysis (SDCA), and Simulated Input Generator (SIG). Each of these nodes is implemented using microcomputer hardware and software, and node intercommunication is performed via a Burroughs loop architecture under control of a distributed master control program (DMCP).

Each node can communicate with any other node on the loop; however, the nodal software for the MSCDM application defines the flow of information in the system. For example, the OCRI terminal normally communicates with the DBMS node, which runs the User Language. The other ESM terminals communicate with the User Language via the loop 4-5 gateway Node 21 (SSCI).

A simulated input generator (SIG) generates inputs to the VSQC, DSQC and BWBSA, which communicate faults to the FIAC module. FIAC generates event reports to the OCRI and DBMS. The PDP 11/40 in loop 2 generates inputs to the SDCA which generates fault reports to the OCRI and DBMS. The DBMS, OCRI and FIAC communicate with the other loops via SSCI.

An LA36 DECWRITER is be used as the OCRI hard-copy terminal attached to node 25. A VT52 DECScope is be used as a local CRT terminal connected to the Program Development Unit (PDU).


The Digital Equipment Corporation System's software for the PDP-11/V03 is contained on 9 - Floppy diskettes conforming to DEC's RX01 Floppy drive format.


The MSCDM applications software which runs on the PDP-11/V03 and the LSI-11/2 nodes is contained on 21- floppy diskettes.

References for the FORTRAN and MACRO-11 languages and the PDP-11 /V03 system used include documentation:

- 1. "RT-11 System Generation Manual"
- 2. "Introduction to RT11"
- "RT-11 System User's Guide"
- 4. "RT-11 System Message Manual"
- 5. "PDP-11 MACRO Language Manual"
- 6. "PDP-11 FORTRAN Language Manual"
- 7. "Advanced Programmer's Guide"


SOFTWARE GENERATION FLOW:







DMCP:










FUNCTION IGETSP(N)










THIS DOCUMENT IS BEST QUALITY PRACTICABLE.
THE COPY FURNISHED TO DDC CONTAINED A
SIGNIFICANT NUMBER OF PAGES WHICH DO NOT
REPRODUCE LEGIBLY.









WORD TOKEN

DETECT SET

LINESWITCH

SET

No

No

Yes

CREATE

G1:=G1-247

ENQUEUE (XINQ,G2)

HEADER AND

EXIT

OPERATOR

END

FORM PACK

FROM BEFORE


AND FORM

PACK


RESET STATUS


WRTTIME: = 0

RESET STATUS





VSQC:



























OCRI:





BWBSA:





























SIG: INPUTS: FROM 3 INDEPENDENT DLVII'S CONNECTED TO VSQC, DSQC, AND BWBSA. VALUE READ WILL BE A CHANNEL OR LINK # TO BE MEASURED.


DVLII INT FROM VSQC, DSQC, OR BWDSA (3 DIFF HANDLERS)


OUTPUTS: MEAS. REPTS. TO VSQC, DSQC, AND BWBSA.
ALSO OCCASIONAL ALARM REPTS. TO PWESA.
ALL DATA TO MONITOR CRT TERMINAL.



























USRLNG:































45










































M4001:
































M6000:




LSIMEM:




LSICPU:





LIURAM:








REPEAT AS ABOVE FOR WRITING AND THEN READING 1010 AND RANDOM $\pm s$. COMPARISON FAILURE AND JUMP





















SUBROUTINE LOADER (INODE):















LOADER PROM:

NODES 21,22,23,27, 28



LOADER PROM:

